

FIG. 1

AT	AID=0000	AID=0001	AID=0002		AID=FFFF
00	ART_EXAMPLE			
01					
02					
	:	:	:		:
	:	:	:		:
	:	:	:		:
FE					
FF					

ADAPTER - TYPE / ADAPTER - ID TO ADAPTER - RESOURCE TABLE ADDRESS

FIG. 2A

RT	ART_EXAMPLE
00	ART ENTRY0
01	ART ENTRY1
02	ART_EXAMPLE ENTRY FOR CQ RESOURCE TYPE
03	
	:
	:
	:
FF	ART ENTRY255

ADAPTER RESOURCE TABLE (ART)

FIG. 2B


DWORD

ART_EXAMPLE ENTRY FOR CQ RESOURCE TYPE

0	ASAB	PRC	MRC
1	SAC	RESERVED	SMC
2	RESERVED	LARID	RESERVED
3	ACCESS-TABLE ADDRESS (ATA) - AT IS FOR ALL CQ RESOURCES		
4	ADAPTER-STORAGE BASE ADDRESS FOR SAT=0		
5	ADAPTER-STORAGE BASE ADDRESS FOR SAT=1		
6-18	:		
19	ADAPTER-STORAGE BASE ADDRESS FOR SAT=15		
BITS	0	8	16
		32	40
		52	63

ADAPTER - RESOURCE - TABLE ENTRY (ARTE)

FIG. 2C



RESOURCE ADDRESS TRANSLATION

FIG. 3